

# Synthesis Technology – E340 Cloud Generator

---

- [Manual PDF](#)
- 

[E340 Cloud Generator Manual \(PDF\)](#)

---

## E340 Cloud Generator (Synthesis Technology) Cheat Sheet

---

### OVERVIEW

---

- **Dual-output VCO** with up to 8 stacked "cloud" VCOs, each with detune and chaos modulation.
  - Outputs super-saw and super-sine oscillations for fat, swarm-like timbres.
  - No built-in CV attenuators—CVs should be attenuated externally if needed.
  - CVs: -5V to +5V range for all modulation inputs.
- 

### Panel Controls & Jacks Reference

---

#### KNOBS & SWITCHES

Control	Function
<b>COARSE</b>	Main frequency, spans 8 octaves.

Control	Function
<b>FINE</b>	Fine frequency, spans ~0.5 octave.
<b>FM AMT</b>	Attenuates FM CV input.
<b>SPREAD</b>	Detunes cloud VCOs relative to base pitch (exponential spread, center position = off).
<b>CHAOS</b>	Adds filtered noise (FM) to detuning, making each VCO "wiggle."
<b>CHAOS BW</b>	Sets bandwidth (speed) of chaos-noise in 6 steps (left = slow, right = fast).
<b>DENSITY</b>	Toggles active VCO count: <b>2, 4, or 8</b> VCOs. More VCOs = reduced amplitude to avoid clipping.

## INPUT JACKS

Jack	Voltage Range	Function
<b>1V/OCT CV</b>	-5V to +5V	Pitch control for all VCOs (use for standard keyboard/gate CV).
<b>FM IN</b>	-5V to +5V	Frequency modulation, mod depth set by FM AMT knob.
<b>SYNC</b>	>+0.25V	Hard sync input. Resets all VCOs to -5V.
<b>SPREAD CV</b>	-5V to +5V	Modulates SPREAD detune, added to knob value.
<b>CHAOS CV</b>	-5V to +5V	Modulates CHAOS depth, added to knob value.
	-5V to +5V	

Jack	Voltage Range	Function
<b>CHAOS BW CV</b>		Modulates CHAOS BW (speed), added to knob value.

## OUTPUT JACKS

Jack	Voltage Range	Function
<b>SAW OUT</b>	-5V to +5V	Sum of detuned saw waves (DC-coupled).
<b>SINE OUT</b>	-5V to +5V	Sum of detuned sine waves (DC-coupled).

---

## QUICK START

1. **Patch 1V/OCT** to sequencer/keyboard CV.
  2. **OUT to VCA/Mixer**: Choose **Saw Out** or **Sine Out**.
  3. **Tune** with coarse/fine knobs.
  4. **Set DENSITY**: Choose 2, 4, or 8 VCOs.
  5. **SPREAD**: Turn up for "cloud" detune effect; patch external CV to sweep amount.
  6. **CHAOS/CHAOS BW**: Add and shape random "wiggle" for extra thickness.
  7. **Sync**: For hard-edge tones, patch clock/square LFO to SYNC.
  8. **FM**: Patch external CV source/noise/LFO/another VCO for classic FM effects. Use FM AMT for depth.
- 

## POWER

- **Eurorack**: +12V @ 55mA, -12V @ 25mA.

- **MOTM:** +15V @ 45mA, -15V @ 15mA.
  - **All panel CV inputs:** -5V to +5V nominal, DC to 8kHz.
- 

## TIPS

---

- Overdriving inputs can shift pitch—keep input levels within -5V/+5V if possible.
  - Each control voltage input is summed with associated knob for total effect.
  - Use external attenuators if finer CV control is needed.
- 

Generated With Eurorack Processor